



RADIO AUX

26 25

24 RV7 RADIO RX

23 SW4 RX MUTE

22 R-0V

21 SW7 M-TYPE

20 SW2_UGain31 TEL2RX SW

19 RV1_U_Att1 TEL1TX TP

18 RV1_U_Att2 TEL2TX TP

17 RV4_UGain31 TEL2RX TP

16 SW1_U_Att2 TEL2TX SW

15 SW1_U_Att1 TEL1TX SW

RADIO TX RV8

E-POL SW5

HS1RX TP RV4_U_Gain1

HS1RX SW SW2_U_Gain1

TX MUTE SW6

E-TYPE SW3

HS2RX TP RV4_U_Gain2

TEL1RX TP RV4_U_Gain32

TEL1RX SW SW2_U_Gain32

HS2RX SW SW2_U_Gain2

M-POL SW8

AUX RX RV2

AUX TX RV3

14 LK OV